



DOSATRON®

WATER POWERED DOSING TECHNOLOGY

D45 Quick Hook-Up Kit

MOUNTING INSTRUCTIONS

Part #: HSPKD45

(Portable Fertilizer System fits 20 GPM Dosatron model.
Dosatron, Quick Hook-Up Kit and Cart sold separately.)



LIT-EN-HSPKD45

Contents Shown Assembled (Dosatron unit sold separately)

4 - Stainless Steel Clamp	1 - 1" Street Elbow FNPT to MNPT
2 - 3/4" Reinforced Hose	2 - Barb Fittings 3/4" MNPT
1 - 1" Elbow FNPT to FNPT	3 - 3/4" Street Elbow FNPT to MNPT
2 - Barb Fittings 1" to 3/4"	1 - 3/4" FNPT to 3/4" Garden Hose
1 - 3/4" Close Nipple	1 - Swivel Adapter 3/4" FNPT to 3/4" Garden Hose
1 - 200 Mesh/80 Micron Filter	1 - Thread Seal Tape
1 - Check Valve	1 - Velcro Strap
Set of Bolts/Nuts	

NOTE: Do not over tighten parts onto the blue inlet and outlet of the unit.





Remove the 10 screws from the back plate, to remove from the back of the DosaCart.



Attach the 20 GPM Dosatron unit bracket on the eyebolts, with the two screws and two nylon locking nuts provided in the hardware bag.



Attach the 200 mesh/80 micron filter to the bottom left of the back of the plate.

4



Re-attach the black plate back onto the DosaCart by installing eight screws around the plate except for the top two screws (these will be used for the crash bar, see step 9).

5



Using the instructions included, assemble the Quick Hook-up kit with the 20 GPM unit.

NOTE: Be cautious not to use excessive force when attaching the fittings onto blue housing of the unit

6



Attach the Dosatron unit and Quick Hook-Up Kit assembly onto the unit bracket.

CALL 1-800-523-8499 FOR SUPPORT

7



Insert the hose onto the filter barb and secure with the clamp.

8



Secure the outgoing hose with a zip tie to the eye hook.

9



Attach the crash bar into place using the remaining two screws.