

This is the User Guide for the Hobby Cultivator by Dosatron.

The Hobby Cultivator leverages Dosatron's unique, water-powered dosing technology to deliver the optimum blend of nutrients and fertilizers directly to your plants.

Applications include liquid fertilizer programs, powder fertilizer programs, concentrated liquid organics, enzymes and beneficial bacteria, propagation and rooting, sanitation, line cleaning, and adjusting pH up or down.

Engineered specifically for indoor home grows and basement grows, the Hobby Cultivator is perfect for applications with an average of 4 to 2 4 lights or 12 to 96 plants.

The standard system comes with four Dosatron pumps but is easily adapted by adding more pumps based on the needs of the application.

It can be used with a direct injection approach or alongside small batch tank systems and recirculating water cultures.

The Hobby Cultivator was designed based on feedback from hobby growers worldwide – people who are passionate about their plants but don't want to be attached to them 24/7.

With the Hobby Cultivator, you can leave your grow knowing Dosatron will continue providing simple, reliable, and repeatable results.

Your plants don't take days off, but luckily neither does Dosatron!

The Hobby Cultivator is not suitable for commercial cultivation.
For our professional series, check out the

Nutrient Delivery System.

CONTENTS

INCLUDED ACCESSORIES	6
TOOLS NEEDED & RECOMMENDED ACCESSORIES	6
SPECIFICATIONS	7
SYSTEM CONFIGURATIONS	8
MOUNTING THE SYSTEM	9
DETERMINE YOUR DELIVERY METHOD	10
IDENTIFYING THE WATER SOURCE	11
CALCULATING FLOW RATES	12
CALCULATING MINIMUM FLOW RATES	13
CALCULATING MAXIMUM FLOW RATES	13
PREPARING THE INJECTORS	14
CONNECTING THE SUCTION HOSE	15
PRIMING THE INJECTORS	15
ADJUSTING THE DOSING RATE	16
ADDITIONAL ACCESSORIES	17
FREQUENTLY ASKED QUESTIONS	18

Congratulations on purchasing your new Hobby Cultivator System by Dosatron!

For questions or troubleshooting, please call us at 1-800-523-8499 or visit our website at www.dosatron.com.





The following basic installation instructions for plumbing systems are intended as general guidance only. Plumbing work may involve complex systems and local building codes. Therefore, it is crucial to consult a qualified professional plumber or contractor before proceeding with any installation if uncertain of requirements.


These instructions do not cover all potential scenarios or variations in plumbing systems, which can vary significantly based on building type, location, and specific requirements. Any deviation from local building codes or improper installation may result in damage, leaks, or other hazards.

By using these instructions, you acknowledge that you are doing so at your own risk. We disclaim any liability for damages or injuries resulting from the use or misuse of this information.

Always prioritize safety and compliance with local regulations when working on plumbing systems. If you are not fully confident in your ability to install plumbing systems safely and correctly, please seek professional assistance.



INCLUDED ACCESSORIES (SYSD15RE05)



TOOLS NEEDED & RECOMMENDED ACCESSORIES


HELPFUL SETUP ITEMS	RECOMMENDED ACCESSORIES
Thread Tape	• ¾" Ball Valve
Tape Measure	• ¾" Check Valve
Phillips-Head Screwdriver	• 3/4" Filter (200 Mesh/80 Micron)
Tongue and Groove Pliers	Booster Pump
 8x - Screws - (Type and size will vary depending on mounting method) 	Pressure Gauge
	 Stock Tank(s) (Large Bins or Buckets)
 8x - Flat Washers for use with screws when mounting brackets 	·




SPECIFICATIONS

Operating Flow Rate	0.5 - 5 GPM
Injection Rate	1.875 - 18.75 mL/G
Injection Rate (Metric)	0.5 - 5 mL/L
Injection Flow	0.015 - 1.5 GPH
Operating Pressure	35 - 87 PSI
Max. Temperature	104°F
Height	15 inches
Width	6.3 inches
Depth	5.21 inches
Weight	2.7 lbs

MOUNTING BRACKET DIMENSIONS







SYSTEM CONFIGURATIONS

Systems can be placed in a straight horizontal line, a U-shape, or serpentine configuration. (See general examples below for reference.)

For all system configurations, the water direction can change, but the *flow of water* must remain consistent for all units, and follow the flow arrow indicated on the front of the units.

See "Figure 1 - Water Flow Arrow" for location of flow arrow on unit.




Figure 1 - Water Flow Arrow



Figure 2 - Horizontal Inline Configuration




Figure 3 - U-Shape Configuration

Figure 4 - Serpentine Configuration




To prevent siphoning the Dosatron units and/or Dosatron systems must be placed ABOVE stock solution containers and not below.




MOUNTING THE SYSTEM

- · Always use studs, suitable anchors, or unistrut for a secure mounting surface
- *Mounting Brackets should be spaced approximately 7.125 inches apart.
- Use the bracket as a guide to mark the positions of the holes for each unit
- Remember to factor in the space between units for the connection unions.

MOUNTING BRACKET & UNION CONNECTION DIMENSIONS





^{*}Measurements may vary slightly - always measure twice before drilling holes.

DETERMINE YOUR DELIVERY METHOD

DIRECT INJECTION METHOD

Direct Injection refers to a Fertigation system that injects individual nutrient parts at set ratios into the water flowing through it and sends it directly to the plants.



Figure 5 - Direct Inject Illustration

BATCH TANK METHOD

Batch tanks typically refer to holding tanks that store a premixed nutrient solution and deliver it directly to your plants whenever valves are opened with the assistance of an on-demand pressure pump.

The Batch Tank Method ensures your water and nutrients are pre-mixed in a holding tank before being delivered to your plants. This fertigation dosing system allows for a more homogeneous solution, and therefore, a more consistent distribution of nutrients and pH levels. This method is popular when using pulse or micro-irrigation techniques and short-burst durations (irrigation times).



Figure 6 - Batch Tank Illustration

IDENTIFYING THE WATER SOURCE

Locate the incoming water source for THE HOBBY CULTIVATOR SYSTEM. Examples of an incoming water source include:

- Reverse Osmosis (RO) Tank
- City Water
- Fresh Water Holding Tank

When using a RO Tank or Fresh Water Holding Tank as your incoming water source, a Booster Pump is necessary. The Booster Pump is required to push the water from the source, through the HOBBY CULTIVATOR SYSTEM, on to the destination (either the Batch Tank Reservoir or directly into the Irrigation Lines.)

When using a Booster Pump to provide adequate pressure and flow to the Dosatron System(s), always place the booster pump on the INLET side of the first Dosatron Unit.

In order to prevent siphoning and/or overdosing, NEVER connect a Booster Pump to the outlet side of a Dosatron system.

If pressure boosting is required after the Dosatron System, then the Batch Tank Method is the preferred method of delivery - as shown in

"Figure 6 - Batch Tank Illustration" on the previous page.



NOTICE

When using the Direct Injection Method, be aware of Irrigation Flow Rates when using the HOBBY CULTIVATOR SYSTEM.



CALCULATING FLOW RATES

(FOR EXISTING IRRIGATION)

STEP 1 - FIND THE TOTAL GPH OF THE ZONE

(# of Emitters on a Zone) x (Rate/Each Emitter in GPH) = TOTAL GPH OF THE ZONE

STEP 2 - CONVERT THE GPH TO GPM OF THE ZONE

(TOTAL GPH OF THE ZONE) / (60 Minutes) = TOTAL GPM OF THE ZONE

-x	/\	М	ы	_

You have 300 emitters each with a flow rate of 0.5 GPH, and you want to find your total flow rate for the zone:

STFP 1

(300 Emitters) x (0.5 GPH) = 150 GPH FLOW RATE OF THE ZONE

STEP 2

(150 GPH) / (60 Minutes) = 2.5 GPM OF THE ZONE

•		-
•		_
-		

CALCULATING MINIMUM FLOW RATES

(FOR NON-EXISTING IRRIGATION)

STEP 1 - FIND THE TOTAL MINIMUM FLOW RATE (GPH) OF THE ZONE

(MIN Flow Rate of System) x (60 Minutes) = TOTAL MINIMUM GPH OF THE ZONE

STEP 2 - FIND THE TOTAL MINIMUM FLOW RATE (GPH) OF EACH PLANT

(MIN FLOW RATE OF ZONE) / (# of plants in the Zone) = TOTAL MIN FLOW RATE/PLANT

EXAMPLE

Using the HOBBY CULTIVATOR SYSTEM (0.5 GPM MIN FLOW RATE)

You have 100 plants on the zone and you want to find your Minimum Flow Rate:

STEP 1

(0.5 GPM) x (60 Minutes) = 30 GPH MINIMUM FLOW RATE OF THE ZONE

STEP 2

(30 GPH) / (100 Plants) = 0.3 GPH PER PLANT MINIMUM

CALCULATING MAXIMUM FLOW RATES

(FOR NON-EXISTING IRRIGATION)

STEP 1 - FIND THE TOTAL MAXIMUM FLOW RATE (GPH) OF THE ZONE

(MAX Flow Rate of System) x (60 Minutes) = TOTAL MAXIMUM GPH OF THE ZONE

STEP 2 - FIND THE TOTAL MAXIMUM FLOW RATE (GPH) OF EACH PLANT

(MAX FLOW RATE OF ZONE) / (# of plants in the Zone) = TOTAL MAX FLOW RATE/PLANT

EXAMPLE

Using the HOBBY CULTIVATOR SYSTEM (5 GPM MAX FLOW RATE)

You have 100 plants on the zone, you want to find your Maximum Flow Rate:

STEP 1

(5 GPM) x (60 minutes) = 300 GPH MAXIMUM FLOW RATE OF THE ZONE

STEP 2

(300 GPH) / (100 plants) = 3 GPH PER PLANT MAXIMUM

PREPARING THE INJECTORS

- Gather units and apply thread tape to ALL MPT (male thread) connection points. Use a minimum of 5 wraps on each MPT (male thread) connection.
- Install unions to all thread taped MPT (male thread) connections this will require unscrewing the union and placing one side of the union on the connections, between units.
- There are two ways to tighten a fitting with threads. You can tighten by hand, tighten by using a wrench, or a combination of the two.
- To ensure you're tightening a fitting properly, start by hand tightening the
 fitting as tight as you can and then add a one-half to one-full turn with a
 wrench.
- By tightening the fitting with your hand, you can ensure that the threads are lined up correctly. If threads crossover, not only does it make it harder to tighten, you also risk stripping the threads.



ALL UNIONS SHOULD BE ORIENTED IN THE SAME DIRECTION.



Figure 7 - Union Orientation

CONNECTING THE SUCTION HOSE

- Unscrew the Suction Hose Nut from the tip of the injector
- Insert Suction Hose Tubing through Suction Hose Nut
- Slide Suction Hose Tubing over the Hose Barb
- Screw the Suction Hose Nut back onto the injector
- Attach the foot filter to the other end of the Suction Hose Tubing
- Refer to "Figure 8 Suction Hose Connection" for reference



Figure 8 - Suction Hose Connection

PRIMING THE INJECTORS

- To "Quick-Prime" the units, ensure that weighted Foot Filters are placed in liquid stock solutions.
- Next, set the injection rate to the maximum value and run the system until the solution is drawn into the injection stem of the Dosatron units.
- Once injectors are primed, turn off the water source and reset each
 Dosatron's injection stem to the proper injection rate for the desired feed or
 recipe.



ADJUSTING THE DOSING RATE

- · To adjust the dosing rate, start by turning the lock nut to the left
- Next, turn the injection sleeve either clockwise or counter-clockwise to your desired rate.
- · Re-tighten the lock nut by turning it to the right.
- Begin at the first unit and adjust to the desired rate for the input.
- Adjust each input until all units are set to the correct injection rate per gallon.
- Recommended rates are provided by nutrient companies and can sometimes be min to max depending on the growth cycle of the plant.
- Some nutrient solutions will require the use of (2) Dosatron units to achieve
 the target injection rates. To do this, begin by placing both weighted foot
 filters and suction hose tubings into the same stock concentrate solution.
 Then, set each Dosatron unit to 50% of targeted injection rate.

EXAMPLE: To achieve a dosing rate of 32mL/gal, you would need to use two Dosatrons, both pulling from the same stock solution. To determine the injection rate to set for each Dosatron, simply multiply 32mL/gal x 50%. Both Dosatron units should be set to 16mL/gal.

- Once the system is primed, take a sample, or if monitoring kit was purchased, validate that EC and pH are within an acceptable range. If needed, take multiple tests and make minor adjustments to system until correct.
- The system is now ready for use to fill Batch Tank or Run Direct Irrigation to plants.
- Be aware that adjustments to input amounts will require retesting and validation.



Figure 9 - Close-up of Injection Scale

ADDITIONAL ACCESSORIES DOSATRO **Expansion Doser** Start Kit Monitor Kit D15RE05VF HYKSTART-STD **HYKMON**

Sunshade MC34-SHADE

Mixing Chamber Kit

HYKMC34





Maintenance Kit

PJDI905

Scan here to check out the additional accessories for your Hobby Cultivator!

Water Hammer Arrestor Kit

WHA34-SS-KIT



FREQUENTLY ASKED QUESTIONS

The Hobby <u>Cultivator</u> leverages Dosatron's unique, water-powered dosing technology to deliver the optimum blend of nutrients and fertilizers directly to your plants. Below are frequently asked questions about our first system geared toward home and hobby growers.

Where can I buy it?

The Hobby Cultivator is for sale in the USA and Canada at shop.dosatron.com. Call us at 1-727-443-5404 if you're outside of North America.

How much does it cost?

The base four-pump system costs \$1500.

What type of applications does it work for?

Applications include liquid fertilizer programs, powder fertilizer programs, concentrated liquid organics, enzymes and beneficial bacteria, propagation and rooting, sanitation, line cleaning, and adjusting pH up or down.

What size applications does it work for?

The Hobby Cultivator is perfect for applications with an average of 4 to 24 lights, covering anywhere from a dozen to a few hundred plants.

What does maintenance look like?

We recommend annual maintenance to keep the Hobby Cultivator running in top shape. We offer an annual seal kit \$65.65.

What is the flow rate?

Flow rates range from 0.5 to 5 gallons per minute.

Does it require electricity?

No. Like all Dosatron pumps, the Hobby Cultivator uses the same water-powered, non-electric proportional dosing technology that we invented back in 1974.

Does it require mixing chambers?

No. Although they can be added, the pumps' design allows for proper blending without mixing chambers.

What is the difference between this and the Nutrient Delivery System?

The Hobby Cultivator was engineered specifically for the scale and price point of home growers with smaller indoor applications versus commercial or outdoor operations. Our pro series provides more diverse flow range, dosing range, pressure range, seal type variety, and are designed for all-day, everyday use.

What additions are available?

To accommodate the needs your specific grow, you can add:

- Expansion unit(s)
- Monitor Kit
- Start Kit
- · Water Hammer Arrestor Kit
- · Mixing Chamber Kit

Have a question not covered here?

<u>Contact us</u> at 1-727-443-5404 We're happy to answer any other questions you might have.

